



LIVE LUGGAGE

POWER ASSISTED

Dear Customer

It is essential you read these advisory safety instructions before using your Power Assisted suitcase. This case has been designed to make your journey less stressful and safer, therefore please read the information below.

1. The PA Series has two tiny, powerful motors inside the wheels that are controlled via sensors in the handle - these operate using torque (not speed). You will need to learn a few techniques to use this new type of suitcase so please take a few minutes to learn how to control your new PA Series case. Sensors in the handle and wheels need only the slightest touch to operate. We have designed this suitcase to be able to be used simply, with the intelligent control system working automatically.

2. For safety reasons the power assisted wheels only activate when the case is being pulled along.

3. This product is powered and has built-in sensors, so therefore you only need the slightest movements to operate the torque sensors that control the speed. The controls needed are directly related to the surfaces you are traveling on. Rough surfaces will need more torque and the power is ideal for gradients. Your PA Series will only operate when going on the flat, up a gradient or over rough surfaces where the sensors will control the power for you.

4. To operate power assistance safely pull the handle out to the required height (see separate operating instruction leaflet) and lock into position. Holding the handle gently tilt the case towards you. Be aware the tilt sensors will operate and kick-in as you gently pull away and start walking. The wheels will automatically operate.

5. PLEASE NOTE: To stop the case going forward tilt the handle upright - this will automatically operate the tilt switch which will turn the power off - you will soon learn to use the power assisted case and adjusting the control pending on the amount of weight you have packed and according to the ideal height that is comfortable for you. Please adjust and implement according to height.

SAFETY INSTRUCTIONS



6. For safety reasons, the Live Luggage case only operates when tilted between 5-35 degrees. If you tilt the case beyond 35 degrees and move, it will go into a neutral position/free mode. If you drop the case with the handle out it will again go into neutral position. Be careful as you tilt it upright when handle is in GO mode.

7. The Anti Gravity handle is designed to shift the main weight of the PA Series over the wheels maximising its centre of gravity (rather like a wheel barrow), however the handle is not designed for children to sit on or to carry heavy secondary bags.

8. This product is not designed to be used on stairs or escalators

9. Please leave the handle in the closed / stow position when not in use - if left out it will draw power from the battery.

IT IS VERY IMPORTANT NO PERSON USES THE WISHBONE HANDLE AS A SEAT

Finally we at Live Luggage wish you a safe and comfortable travel experience but safety is of paramount importance to us so please take care and have a pleasurable journey.

